



**Non-stop  
dogwear**

UNLEASH YOUR POTENTIAL

Warning: Indicates the inherent dangers and responsibility the user assumes when using a Non-stop dogwear product.

nonstopdogwear.com



**FAQ - CONTACT - QUESTIONS?**  
supprt@nonstopdogwear.com

**HEAD OFFICE**  
Non-stop dogwear AS  
Høllevegen 395  
2372 Brøttum  
Norge

## BOOTIES

### 1 PRODUCTS



### 3 LIFE SPAN

Frequency of use	Approximate durability
Never used	Max 10 years
Once or twice a year	Up to 7 years
Several times a month	Up to 3-5 years
Daily or every week	Up to 2 years

### 4 CLEANING



MAX 30°C

### 5 DRYING



### 6 STORAGE/TRANSPORT



MAX +55°C  
MIN -35°C



## NON-STOP DOGWEAR SAFETY GUIDELINES

Thank you for purchasing this Non-stop dogwear product. We highly appreciate your choice and wish you lots of pleasure using this product.

These safety guidelines must be carefully read and clearly understood. Keep this safety guidelines for the future.

As Non-stop dogwear cannot control the quality of products sold by unauthorized sellers, including unauthorized Internet sites, this safety instruction applies only to products that were sold by Non-stop dogwear or a Non-stop dogwear authorized retailer, unless otherwise prohibited by law.

Non-stop dogwear advises the correct use of the products: Therefore always follow these safety guidelines to ensure correct use of the products both for dogs and for humans. The warning symbols inform you of some potential dangers related to the use of your equipment. Only certain techniques and uses are described. Check nonstopdogwear.com for the most up-to-date information. Any misuse of this equipment could create additional danger. Contact Non-stop dogwear if you have any doubts or difficulty understanding these instructions.

### WARNING

By using this product you accept and understand all the conditions, warnings and risks the use of the product might bring both for you and for your dog(s).

You alone are responsible for correct use of the product. It is your responsibility to use the product correctly and to make sure that the product is the right size for your dog taking into account the dogs physical measurements, the dogs weight and the weather conditions when using the product.

Incorrect use can lead to serious damage or even death.

The dog should never handle the product without supervision by the owner or another responsible adult. Dogs are, as a common rule, not able to understand risks or to avoid dangers. Therefore, dogs must never be left alone with any Non-stop dogwear products including, but not limited to, packaging at any time.

The risk of products being eaten by dogs or in other ways harming the dog is highly expected and must be prevented by making sure that the dog is not handling or left alone with products without adult human supervision.

Using Non-stop dogwear products will give an increase of excitement to the dog for activities. This in turn can cause a greater risk of danger to children. To reduce the risk of danger, make sure the dog is always under control before activity with children. Therefore, make sure that the eagerness of the dog does not endanger other humans or animals.

The product must not be used in other situations or conditions than those they are designed for.

If the product is bought second hand, you can never trust the product to fill its purpose and Non-stop dogwear will not be responsible.

The product must be inspected before and after each outing. The product shall not be used if the product is damaged due to misuse or excessive use, accidental damage, alteration or modifications to the product, or neglect, negligence, or improper care.

Dry the product thoroughly after each outing and store it in a dry, cool place out of direct sunlight and follow the care instructions specific to each product.

All use of Non-stop dogwear products in contradiction of the above described instructions are unacceptable and might be a threat to humans and dogs health and life.

Non-stop dogwear will under no circumstance have legal liability or legal responsibility for the use or the misuse of the products.

## EN BOOTIES

### BEFORE USE

Read the safety guidelines for Non-stop dogwear products carefully.

All kinds of use of Non-stop dogwear products in contradiction of the safety guidelines are unacceptable and might be a threat to humans and dogs life and health.

- It is essential to use the correct size that fits well.
- Make sure that there is no damage to the booties.
- Make sure there are no deformation or weakness of the booties.
- Ensure that the booties are dry, clean and is not visibly worn, stretched, or harmed.
- Ensure that all straps are correctly fastened and properly adjusted to the dog before use.
- Make sure that the temperature is not too warm or too cold before each outing with your dogs.
- When tightening the booties, with the elastic under tension, you should be able to fit one finger in between your dog's leg and the bootie for large dogs (size L and up), a bit less for medium and small dogs.

### DURING USE

If deformation is detected on the booties, or any other malfunctions of the booties is detected, the booties must not be used.

If cuts or other injuries are found at the booties or in the webbing, the booties must not be used.

### AFTER USE

- Clean and dry the booties.
- Check if any weaknesses or damages has occurred.
- Store the booties according to the description on the website and due to the safety guidelines.

### WARNING

This Non-stop dogwear product is designed for use by dogs only.

### Challenges and threats that might occur when using the booties:

- Use of the booties not in accordance with the safety and security guidelines might cause injuries.
- Use of the booties might cause problem with the wolf claw.
- The booties are only to be used when training or competing with dogs.
- Injuries can occur when wrongly used f.i too loose or too tight booties.
- Injuries can occur if the booties are used for other purposes than it is made for.
- The booties might cause decreased blood flow if used incorrectly.
- Running with the booties in the woods or at glaciers can lead to injuries.
- The booties are not designed to protect you or your dog when climbing or parachuting.
- The booties must not be used on extreme surfaces (heat, sharp objects etc.).
- The booties must not be worn when the dog is in no activity.
- The booties must be removed as soon as the activity is ended.
- The booties shall not be used when the dog is back in the car after training/competition.
- The booties can be swallowed by the dog and thereby cause big injuries in the intestines.
- The elastic strap must not be tightened too much, reducing the blood flow of the dog.

### LIFE SPAN AND REPLACEMENT

The life span of the product mainly depends on the type and frequency of use as well as on external influences. Some factors that impact the life span will not be visible if you don't know the history and exposure of the booties to environmental and chemical factors (petroleum, oils, lubricants, acids, etc.). When approaching the durability limits or latest at the end of the maximum life span indicated, the product must be removed from use. See figure 3 for estimation of life span for your product.

## NO POTESOKKER

### FØR BRUK

Les sikkerhetsretningslinjene for Non-stop dogwear sine produkter nøye.

Alle typer bruk av Non-stop dogwear sine produkter som strider med sikkerhetsretningslinjene er uakseptabelt og kan være en trussel for mennesker og hunders liv og helse.

- Det er essensielt å bruke riktig størrelse som passer godt.
- Forsikre deg om at det ikke er noen skade på potesokkene.
- Forsikre deg om at potesokkene ikke har noen deformasjoner eller svakheter.
- Forsikre deg om at det ikke er noen deformasjoner eller skader på potesokkene.
- Forsikre deg om at potesokkene er tørre, rene og ikke synlig slitt, strukket eller skadet.
- Forsikre deg om at alle stropper er korrekt festet og riktig justert til hunden før bruk.
- Forsikre deg om at temperaturen ikke er for varm eller for kald før enhver bruk av produktet med hunden din.

### UNDER BRUK

Hvis deformasjon eller enhver annen funksjonsfeil på potesokkene oppdages må ikke potesokkene brukes.

Ved funn av kutt eller andre skader på potesokkene eller webbingen må ikke potesokkene brukes.

### ETTER BRUK

- Vask og tørk potesokkene.
- Sjekk om noen form for svakhet eller skade har oppstått.
- Oppbevar potesokkene som beskrevet på nettsiden og i disse sikkerhetsretningslinjene.

### ADVARSEL

Dette produktet fra Non-stop dogwear er kun designet for bruk på hunder.

- Utfordringer og farer som kan oppstå ved bruk av potesokkene:
- Bruk av potesokkene som ikke samsvarer med sikkerhetsretningslinjene kan lede til skader.
- Bruk av potesokkene kan medføre problemer med ulveflo.
- Potesokkene skal bare brukes når du trener eller konkurrerer med hunden.
- Skader kan oppstå ved feil bruk, for eksempel hvis potesokkene sitter for trangt eller for løst.
- Skader kan oppstå hvis potesokkene brukes til andre formål enn det de er laget for.
- Potesokkene kan føre til dårligere blodgjennomstrømming ved feil bruk.
- Løping med potesokker i skogen eller på isbreer kan lede til skader.
- Potesokkene er ikke designet for å beskytte deg eller hunden ved klatring eller fallskjermhopping.
- Potesokkene må ikke brukes på ekstreme overflater (varme, skarpe objekter etc.).
- Potesokkene må ikke brukes når hunden ikke er i aktivitet.
- Potesokkene må tas av så snart aktiviteten har opphørt.
- Potesokkene skal ikke brukes når hunden ligger i bilen etter trening/konkurranse.
- Potesokkene kan svelges av hunden og dermed forårsake skade på innvoller.
- Den elastiske stroppen må ikke strammes for hardt, da det vil redusere blodgjennomstrømmingen.

### LEVETID OG UTSKIFTNING

Produktets levetid avhenger i hovedsak av brukstype og frekvens, samt eksterne faktorer. Noen av faktorene som kan påvirke levetiden er ikke synlige, hvis du ikke vet historikken og eksponeringen potesokkene er utsatt for av miljø og kjemikalier (petroleum, oljer, smøremidler, syrer etc.). Når grensen for varighet nærmer seg, og senest ved slutten av den maksimale levetiden som er indikert, må produktet tas ut av bruk. Se fig. 3 for estimert levetid for ditt produkt.

## SE SOCKOR

### FÖRE ANVÄNDNING

Läs säkerhetsriktlinjerna för Non-stop dogwear produkter noggrant

All slags användning av Non-stop dogwear produkter i strid med säkerhetsriktlinjerna är oacceptabelt och kan vara ett hot mot människors och hundars liv och hälsa.

- Det är viktigt att använda rätt storlek som passar bra.
- Se till att det inte finns några skador på sockarna.
- Se till att det inte finns någon skada eller svaghet på sockarna.
- Se till att sockarna är torra, rena och inte är synligt slitna, sträckta eller skadade.
- Se till att alla band är korrekt fastsatta och korrekt anpassade till hunden före användning.
- Se till att temperaturen inte är för varm eller för kall inför varje aktivitet med din hund.

### UNDER ANVÄNDNING

Om skada upptäcks på sockarna, eller om några andra felfunktioner på sockarna upptäcks, får sockarna inte användas.

Om skärsår eller andra skador upptäcks på produkten eller i bandet får produkten inte användas.

### EFTER ANVÄNDNING

- Rengör och torka sockarna.
- Kontrollera om några svagheter eller skador har uppstått.
- Förvara sockarna enligt beskrivningen på webbplatsen och enligt säkerhetsriktlinjerna.

### VARNING

Denna Non-stop dogwear produkt är endast avsedd att användas av hundar.

### Utmaningar och hot som kan uppstå när du använder sockarna:

- Användning av sockarna som inte överensstämmer med säkerhets- och skyddsriktlinjerna kan orsaka skador
- Användning av sockarna kan orsaka problem med sporrer
- Sockarna får endast användas vid träning eller tävling med hundar
- Skador kan uppstå när produkten felaktigt används, för lösa eller för hårda band
- Skador kan uppstå om sockarna används för andra ändamål än de är gjorda för
- Sockarna kan orsaka anemi om de används felaktigt
- Att springa med sockarna i skogen eller vid glaciärer kan leda till skador (som anemi)
- Sockarna är inte utformade för att skydda dig eller din hund när du klatrar eller hoppar fallskärm
- Sockarna får inte användas på extrema ytor (värme, vassa föremål etc.)
- Sockarna får inte bäras när hunden inte är i någon aktivitet
- Sockarna måste tas bort så snart aktiviteten är avslutad
- Sockarna får inte användas när hunden är tillbaka och ligger i bilen efter träning/tävling
- Sockarna kan sväljas av hunden och därmed orsaka stora skador i tarmen
- Den elastiske remmen får inte dras åt för mycket vilket minskar hundens blodflöde

### LIVSLÅNGD OCH ERSÄTTNING

Produktens livslängd beror huvudsakligen på typ och frekvens av användning samt på yttre påverkan. Vissa faktorer som påverkar livslängden kommer inte att synas om du inte känner till sockarnas

